



TROUBLE SHOOTING GUIDE BALER WILL NOT OPERATE

A) No Power

1. Check main power source
2. Check if power key switch is on
3. Check if gate is down
4. Check bale chamber door is closed

B) Door Switch

1. Main door may not be closed properly against switch

C) Material Jamming Ram

1. Remove all jamming material from ram

D) Check Hydraulic Fluid

1. If unit is low add Hydraulic Fluid (see Baler Manual)

E) Spray Compression Piston

1. Spray surface of the compression arm with WD-40 spray

BALER TRAINING:

Do you have a new associate that has just joined your store team?

Or maybe you'd like to run a refresher training program for all associates on how to safely run the baler in your store.

Well we have worked with the vendor that supplies balers for the chain and have made an online training video available for download to your store.

We have also included the direct link to a PTR training video online:

<http://www.ptrco.com/infoliterature.html>